

Asendab akusid:

DELL

0C601H
0D608H
0GP952
0GW240
0GW252
0RN873
0RU586
0WK379
0X284G
0XR693
0XR694
0XR697
K450N
J399N
312-0625
312-0626
312-0633
312-0634
312-0763
312-0844
C601H
CR693
D608H
GP252
GP952
G555N
0F965N
GW240
GW241
GW252
HP277
HP287
HP297
M911G
P505M
PD685
RN873
RU573
RU583
RU586
0XR682
HP297
RW240
UK716
WK371
WK379
WK380

Sobib mudelitele:

Dell

Inspiron 1525
Inspiron 1526
Inspiron 1440
Inspiron 1750
Vostro 500

WK381
WP193
X284G
XR682
XR693
XR694
XR697
OC601H
OUK716
OCR693
OGP252
OGW241
OHP277
OHP287
OHP297
OM911G
OP505M
OPD685
ORU573
ORU583
ORW240
OWK371
OWK380
OWK381
OWP193
451-10478
451-10533