

Asendab akusid:

AA-PB2NC3B
AA-PB4NC6B
AA-PB9NC6W
AA-PB2NC6B
AA-PB4NC6B/E
AA-PB9NC6W/E
AA-PB2NC6B/E
AA-PB6NC6B
AA-PL2NC9B

Sobib mudelitele:

Samsung 70A00D/SEG
Samsung R39-DY04
Samsung R458
M60 Aura T7500 Calipa
M60-Aura T7500 Calipa
Samsung NP Series
NP-R40 Plus
NP-R65
Samsung P210 Series
P210-BA02
P210-BS04
P210-XA01
Q320-Aura P7450 Benks
Samsung P460 Series
P460-44G
P460-AA02
P50 Pro T2400 Tytahn
P50 Pro T5500 Teygun
P50 T2400 Tytahn
P50-00
P50-CV03
P560
P560-54P
P560 AA03
P60 Pro T2600 Taspra
P60
P60-CV01
Q210 AS01
Q210
Q210-FS02DE
Samsung R40 Series
R40 XIP 2055
R40 XIP 5500
R40/K00/SEG
R40-Aura T2080 Deron
R40E003/SEG
R40FY04/SEG
R40K003/SEG
R40-K006
R40-K009
R40-K00E
R40-T2300
R41-T2060 Collin
R410
R410-XA03
R45 Pro C1600 Buliena

R45
R45-K004
R45-K007
R45-K03
R460-AS06
R460-XS04
R505 FS03
R509-FA02DE
Samsung R510 Series
R510 AS05
R510 FA01
R510 FA07
R510 FS01
R510 FS0A
R510 XE5V 7350
R510-AA01DE
R510-FA04DE
R510-FS07DE
R510-FS0DDE
R510-FSX1DE
R560-AS06DE
R560-AS0DDE
R560-AS0GDE
R60 Aura T2130 Daliwa
R60 Aura T5250 Danica
R60 Aura T5250 Donna
R60 Aura T7250 Divial
R60-Aura T2330 Diazz
Samsung Q310
Samsung R39-DY06
Samsung M60 Series
M60 Aura T7500 Cruza
M60-Aura T7500 Caralee
NP-P50
NP-R40
NP-R70
P210
P210-BS01
P210-BS05
Samsung Q320 Series
Q320-Aura P7450 Darjo
P460
P460-44P
P460-Pro P8600 Pompeji
P50 Pro T2600 Tygah
P50 Pro T7200 Torrin
P50 T2600 Tygah
P50-C003
P50-CV04
P560-52P

P560 AA01
P560 AA04
P60 Pro
P60-01
P60-CV03
Q210 AS05
Q210-FA03DE
Q210-FS03DE
R40 XIC 2050
R40 XIP 2250
R40 XIP 5510
R40-Aura C430 Corin
R40-Aura T2250 Dooly
R40-EL1
R40K001/SEG
R40K004/SEG
R40-K007
R40-K00A
R40-K00F
Samsung R41 Series
R41-T2250 Madea
R410-XA01
Samsung R45 Series
R45 Pro T5500 Bernie
R45-1730 Cutama
R45-K005
R45-K00D
Samsung R460 Series
R460-AS09
Samsung R505 Series
R505 FS04
R509-FA03DE
R510 AS02
R510 AS07
R510 FA02
R510 FA09
R510 FS08
R510 XE2V 5750
R510 XS01
R510-AS01
R510-FA05DE
R510-FS0BDE
R510-FS0GDE
Samsung R560 Series
R560-AS0BDE
R560-AS0EDE
R560-AS0HDE
R60 Aura T2330 Deesan
R60 Aura T5250 Deeloy
R60 Aura T5450 Darlis

R60-Aura T2130 Daliwa
R60-Aura T5250 Danica
Samsung Q310-AS04DE
Samsung R408
M60 Aura T5450 Chartiz
M60-Aura T5450 Chartiz
M60-Aura T7500 Cruza
NP-P60
NP-R45
NP-X60
P210-BA01
P210-BS02
P210-Pro P8400 Padou
Q320-32P
Q320-Aura P8700 Balin
P460-42P
P460-AA01
Samsung P50 Series
P50 Pro T5500 Tahlia
P50 Pro
P50
P50-C004
Samsung P560 Series
P560-54G
P560 AA02
Samsung P60 Series
P60 T2600 Taspra
P60-C003
Samsung Q210 Series
Q210 FS01
Q210-FA04DE
Q210-FS04DE
R40 XIP 2050
R40 XIP 2255
R40
R40-Aura C440 Chrizz
R40-Aura T5500 Dilana
R40FY03/SEG
R40-K003
R40-K005
R40-K008
R40-K00D
R40-T2300 Caosee
R41-T2050 Malaido
Samsung R410 Series
R410-XA02
R45 Pro 1730 Bizzlay
R45 Pro
R45-C1500 Cerona
R45-K006

R45-K02
R460
R460-BS04
R505 FS02
R505-FS05DESamsung R509 Series
R509-XA01DE
R510 AS04
R510 AS08
R510 FA06
R510 FA0E
R510 FS09
R510 XE2V 7350
R510
R510-BA01
R510-FS05DE
R510-FS0CDE
R510-FS0JDEP-R51
R560-AS05DE
R560-AS0CDE
R560-AS0FDE
Samsung R60 Series
R60 Aura T2330 Diazz
R60 Aura T5250 Deven
R60 Aura T5450 Davu
R60-Aura T2330 Deesan
R60-Aura T5250 Deeloy